

East Elite

Lifting Equipment




Lower Position

Pull up the fingertip for lowering .



Neutral Position

Keep in the position to push & pull the truck.



Lifting Position

Push down the fingertip for pump lifting .



◆ One-piece cast pump with reliable oil-proof hydraulic systems .



◆ Reinforced for added strength of load capacity .



◆ Effortless pallet entry/exit rollers to make it easier to push and pull pallet truck .



STANDARD PALLET JACK

Colour Available: Orange

Hand and Foot Operated

Fork Size: 1200 *680 mm

Load Capacity: 3 000 kg

Lowered Height: 85mm

Raised Height: 185 mm

Individual Fork Width: 160 mm

Wheels: Double Bogie Nylon or Poly Urethane

Email: sales@eastelite.co.za

Telephone: 079-885-0364

Website: www.eastelite.co.za

